



# **Mobile NoteTaker Firmware Upgrade procedure**



## General

Pegasus Mobile NoteTaker base unit consist of upgradeable firmware portion. Upgrading the base unit firmware will be done once Pegasus releases a new/updated version of the firmware.

Use Pegasus Firmware Update Utility to update your Mobile NoteTaker firmware.

## Needed Hardware

These are the hardware components you will need in order to upgrade your firmware:

- Mobile NoteTaker base unit
- Mobile NoteTaker USB cable
- PC


## Needed software

- Latest Firmware Update Utility from Pegasus web site


## How to upgrade

### NOTES:



- **Upgrading your firmware will not delete your stored Notes within the Mobile unit.  
However, we recommend to upload all your notes from the Mobile Unit to your NoteTaker application.**
- **Do not reset your PC or disconnect the base unit from the PC while performing this action**
  
- Download the latest Firmware Update Utility
- Make sure the base unit is connected to the PC, using the USB cable
- Make sure you close the NoteTaker application, or any application used with the product
- Run the Firmware Update Utility  
The following dialog will appear:



- Click 'Next'
- The following screen will appear, showing you your current version and the new version you will be upgraded to:



- Click 'Update'
- The following screen will appear



- Pressing 'Finish'